

HydraSleeve with Wide Mouth 4-2" adapter and/or SWA

(Surface Water Adapter)

1. Assemble using Super/SkinnySleeve Assembly Instructions
2. 4-inch Spring Clip comes with the Wide Mouth 4-2" adapter for attaching to tether. Connect a measuring tape or other type of line to SWA as seen in the photo (not included).
3. Lower at a slow steady rate to desired sampling depth. Place top of sampler at the bottom of the sampling interval.
4. Rapidly pull up on the line approximately 3 feet (1 meter); allow it to drop back down to the starting depth; then recover at a fast steady pace to the surface.
5. Remove the bottom weight from the sleeve and detach the sleeve from the adapter. A HydraClamp (sold separately) will come in handy to disassemble the filled sleeve. The HydraClamp can be attached to the outside of the sleeve at the check valve to seal the sample in the bag while removing the Surface Water Adapter.
6. Decant the sample using the discharge straw following the HydraSleeve Field Manual Instructions.

