

HydraSleeve 1-inch SkinnySleeve with Top Weight assembly



COMPONENTS:
 1-INCH TOP WEIGHT
 1-INCH PVC COLLAR
 1-INCH HYDRASLEEVE SKINNYSLEEVE
 CABLE TIE (save for future assemblies)
 2 WEIGHT CLIPS
 8-OUNCE BOTTOM WEIGHT



Remove the HydraSleeve from the package - do not discard dispensing straw. Insert the cable tie into the bottom (weight) hole in the tail of the HydraSleeve. Pull it through to the knob.



Using the cable tie as an insertion tool, feed the bottom of the HydraSleeve into the top weight threaded end. Pull it through until the check valve area has reached the threaded portion of the top weight.



Take apart the PVC collar adaptor. Carefully install the bottom (female threads) portion by inserting the check valve area of the HydraSleeve through the bottom of the collar. Thread this onto the top weight.



Gently stretch the lip of the HydraSleeve above the check valve. Insert the threaded portion of the smaller 1/2 (male threads) of the collar into the top of the HydraSleeve. Don't go past the check valve line.



Carefully pull the bottom of the sleeve along with the top collar so that the two portions of the collar meet. Thread these together with the lip of the HydraSleeve inbetween the threads.

